

# OPTIMAL OPERATING TEMPERATURES

for all tire types

(Parameters shown are based on actual outside temperatures.)



**WINTER**

+ 7° C



- 40° C

**ALL SEASON**

+ 30° C




- 15° C

**SUMMER**

+ 50° C



+ 7° C



**We strongly recommend the installation of 4 Winter Tires for Maximum Safety at low temperatures.**